

RISO TIPS



1. The riso machine doesn't manage well with paper **over 300gsm**. Try stick to **lighter paper** for better results!
2. The printer also **doesn't print above 300dpi**. Save some space and keep **smaller files**!
3. For the best results, make sure your work is **greyscale**. Remember the **darkest** blacks will result in the most **saturated** riso ink!
4. **6pt text** (like this) is the lowest size the riso can print reliably. Anything lower will begin to be **illegible**. (like that)
5. Single-Layer **PDFs** for each colour, or multi-layered, labelled **PSDs** are the simplest format to print riso from!
6. Try leave a **5mm blank border** around your work when printing. It will help with both alignment and trimming as well as preventing **paper jams**!